

Classroom Operating Instructions

Turning on the System

- Push any of the input select buttons on the keypad
 - PC
 - Laptop
 - Wireless (AppleTV)
- This will turn the projector on, lower the screen, adjust the lights and lower the shades where applicable.
- The keyboard, mouse, and monitor are connected to the PC in the teacher's station.
- The knob on the right is a volume control.

Connection Options

- You can insert a USB drive into the front of the PC for a presentation.
- The PC is connected to the network if you need something from the web
- A laptop can be connected to the system using the VGA/Audio cable or the HDMI cable.
 - The system will sense which connection you're using and display it from the projector.
- The AppleTV can be used if you have an Apple product with AirPlay and the pick the AppleTV that's named after the classroom.
- For non-Apple products you can install a program called AirParrot which operates the same as AirPlay.

When finished with your session press the system off button. This will turn the projector off, raise the screen, adjust the lights and raise the shades where applicable. The keypad will blink until the projector is cooled down enough to turn the system on again.

Contact ITS if you run into any technical problems.

727-864-8318 or itshelp@eckerd.edu